



# SERVICE MANUAL

COMPACT DISC RADIO  
CASSETTE RECORDER

BASIC TAPE MECHANISM : ZZM-1 YR2NF  
BASIC CD MECHANISM : DA11T3C

This Service manual contains information about the difference between CSD-A110<HR(S)> and CSD-A100<HR(S,L)>. If requiring the other information, Service manual of CSD-A110<HR(S)> (S/M Code No. 09-003-342-2R2).

# ALTERRATION LIST

## MECHANICAL PARTS LIST 1/1

REF. NO	PART NO.	KANRI NO.	DESCRIPTION
1	8A-CDA-072-010		WINDOW, CASS EZ L<L>
1	8A-CDA-062-010		WINDOW, CASS D<S>
3	8A-CDA-003-110		LID, CASS<S>
3	8A-CDA-069-110		LID, CASS EZ L<L>
5	8A-CDA-042-010		WINDOW, LED LOW LH<L, S>
6	8A-CDA-145-110		CABI ASSY, FRONT LOW HE L<L>
6	8A-CDA-054-110		CABI ASSY, FRONT LOW HR<S>
8	8A-CDA-020-110		KNOW, SL BAND<S>
8	8A-CDA-154-110		KNOW, SL BAND HE L<L>
9	8A-CDA-046-110		WINDOW, TU HR<S>
9	8A-CDA-148-010		WINDOW, TU HE L<L>
11	8A-CDA-019-110		KEY, VOL<S>
11	8A-CDA-080-110		KEY, VOL EZ L<L>
12	8A-CDA-061-210		LID, CD D<S>
12	8A-CDA-070-210		LID, CD EZ L<L>
21	8A-CDA-016-110		KEY, CD <S>
21	8A-CDA-078-110		KEY, CD EZ L<L>
23	8A-CDA-017-110		KEY, MODE<S>
23	8A-CDA-079-110		KEY, MODE EZ L<L>
26	8A-CDA-012-110		CHAS, CD<S>
26	8A-CDA-180-110		CHAS, CD EZ L<L>
29	8A-CDA-010-210		HANDL, ARM<S>
29	8A-CDA-074-110		HANDL, ARM EZ L<L>
30	8A-CDA-011-110		HANDL, COVER<S>
30	8A-CDA-075-110		HANDL, COVER EZ L<L>
34	8A-CDA-027-110		KEY, PAUSE<S>
34	8A-CDA-088-110		KEY, PAUSE EZ L<L>
35	8A-CDA-026-110		KEY, STOP<S>
35	8A-CDA-086-110		KEY, STOP EZ L<L>
36	8A-CDA-025-110		KEY, FF<S>
36	8A-CDA-085-110		KEY, FF EZ L<L>
37	8A-CDA-024-110		KEY, REW<S>
37	8A-CDA-086-110		KEY, REW EZ L<L>
38	8A-CDA-023-110		KEY, PLAY<S>
38	8A-CDA-084-110		KEY, PLAY EZ L<L>
39	8A-CDA-022-110		KEY, REC<S>
39	8A-CDA-083-110		KEY, REC EZ L<L>
42	8A-CDA-021-110		KNOB, RTRY TU<S>
42	8A-CDA-082-110		KNOB, RTRY TU EZ L<L>
49	8A-CDA-038-110		CABI, REAR LOW LH<S>
49	8A-CDA-147-110		CABI, REAR LOW HE L<L>
50	8A-CDA-005-110		LID, BATT<S>
50	8A-CDA-071-110		LID, BATT EZ L<L>

アイワ株式会社 〒110-8710 東京都台東区池之端1-2-11 ☎03(3827)3111 (代表)

**AIWA CO., LTD.** 2-11, IKENOHATA 1-CHOME, TAITO-KU, TOKYO 110-8710, JAPAN TEL:03 (3827) 3111